# shaobow-ps1-report

Shaobo Wang

## ps1-2


#### Terminal printout:


PS C:\Users\Brad\iCloudDrive\CMU\_Spring2022\_Files\Spring22\_24678\ProblemSets\ps1\ps1-2> python ps1\_2.py circuit.png B
PS C:\Users\Brad\iCloudDrive\CMU\_Spring2022\_Files\Spring22\_24678\ProblemSets\ps1\ps1-2> python ps1\_2.py crack.png D

PS C:\Users\Brad\iCloudDrive\CMU\_Spring2022\_Files\Spring22\_24678\ProblemSets\ps1\ps1-2


python ps1\_2.py circuit.png B
python ps1\_2.py crack.png D

#### Image output:





File list in the ps1-2 folder:



#### Python script:

```
import cv2
import sys
import numpy as np
MAXVALUE = 255
RED = (0, 0, MAXVALUE) # BGR color red
# insert string before
def insert_name(name, str2add):
    dot_idx = name.find(".")
    new_name = name[:dot_idx] + str2add + name[dot_idx:]
    return new_name
if __name__ == '__main__':
    # get input arguments
    args = sys.argv
    assert (len(args) == 3) # make sure two arguments input
    img_name = args[1] # input image path
    if args[2] == "B" or args[2] == "b":
        emp_bright = True # emphasize brighter
    elif args[2] == "D" or args[2] == "d":
        emp_bright = False
    else:
        sys.exit("Wrong input arguments.")
    # read original image
    img = cv2.imread(img_name)
    if img is None:
        sys.exit("Could not read the image.")
    cv2.imshow(img_name, img)
    # convert image to gray scale
    img_gray = cv2.cvtColor(img, cv2.COLOR_BGR2GRAY)
    img_gray_name = insert_name(img_name, "_grayscale")
    cv2.imshow(img_gray_name, img_gray) # display image
    cv2.imwrite(img_gray_name, img_gray) # save image
    # convert image to binary
```

```
thresh = (np.average(img_gray) + MAXVALUE / 2) / 2 # calculate appropriate
threshold
    if emp_bright:
        # emphasize part in white
        _, img_bin = cv2.threshold(img_gray, thresh, MAXVALUE,
cv2.THRESH_BINARY)
   else:
        # emphasize part in black
        _, img_bin = cv2.threshold(img_gray, thresh, MAXVALUE,
cv2.THRESH_BINARY_INV)
    img_bin_name = insert_name(img_name, "_binary")
    cv2.imshow(img_bin_name, img_bin)
   cv2.imwrite(img_bin_name, img_bin)
    # convert image to output
   img_output = img.copy()
    img_output[img_bin == MAXVALUE] = RED # white part of binary in red
   img_output_name = insert_name(img_name, "_output")
   cv2.imshow(img_output_name, img_output)
    cv2.imwrite(img_output_name, img_output)
   cv2.waitKey(0)
    cv2.destroyAllWindows()
```

### ps1-3

#### Terminal printout:


```
PS C:\Users\Brad\iCloudDrive\CMU_Spring2022_Files\Spring22_24678\ProblemSets\ps1\ps1-3> python ps1_3.py smiley.jpg
Press 'S' to save and exit
Adjusted gamma value is: 0.66
PS C:\Users\Brad\iCloudDrive\CMU_Spring2022_Files\Spring22_24678\ProblemSets\ps1\ps1-3> python ps1_3.py carnival.jpg
Press 'S' to save and exit
Adjusted gamma value is: 2.69
```

```
python ps1_3.py smiley.jpg
python ps1_3.py carnival.jpg
```

#### Image output:



File list in the ps1-2 folder:



#### Python script:

```
import cv2
import sys
import numpy as np
MAXVALUE = 255
K = 100 # scale factor for trackbar
gamma = 1.0 # init gamma value
GAMMA\_MAX = int(6 * K) # max gamma value 4.0
win_original_name = "Original Image"
win_corrected_name = "Gamma-corrected Image"
# insert string before
def insert_name(name, str2add):
    dot_idx = name.find(".")
    new_name = name[:dot_idx] + str2add + name[dot_idx:]
    return new_name
# gamma correction
def gamma_correct(img_in, gm):
    lut = np.zeros((1, MAXVALUE+1), dtype=np.uint8) # init look-up table
    for i in range(256):
        lut[0, i] = np.clip(pow(i/MAXVALUE, gamma)*MAXVALUE, 0, MAXVALUE)
    img_out = cv2.LUT(img_in, lut) # look-up table transform
    return img_out
# trackbar helper function
def on_gamma_trackbar(val):
    global gamma
    gamma = va1/K
    cv2.setTrackbarPos("Gamma", win_corrected_name, int(gamma*K))
if __name__ == "__main__":
    # get input arguments
```

```
args = sys.argv
   assert (len(args) == 2) # make sure two arguments input
   img_name = args[1] # input image path
   cv2.namedWindow(win_original_name)
   cv2.namedWindow(win_corrected_name)
   # read original image
   img = cv2.imread(img_name)
   if img is None:
       sys.exit("Could not read the image.")
   cv2.imshow(win_original_name, img)
   gamma_init = int(gamma*K) # init position in trackbar
   cv2.createTrackbar("Gamma", win_corrected_name, gamma_init, GAMMA_MAX,
on_gamma_trackbar)
   print("Press 'S' to save and exit")
   while True:
       # gamma correct image wrt trackbar val
       img_output = gamma_correct(img, gamma)
       cv2.imshow(win_corrected_name, img_output)
       key = cv2.waitKey(30) # wait 30ms
       if key == ord("s"):
           # press 'S' to save
           img_output_name = insert_name(img_name, "_gcorrected")
           cv2.imwrite(img_output_name, img_output)
            print("Adjusted gamma value is: " + str(gamma))
       elif key == ord("q") or key == ord("x") or key == 27:
            # press 'q', 'x', 'ESC' to quit
           break
   cv2.destroyAllWindows()
```